



- Where the water hammer generate in the piping system, the flexible joint might be damaged. Take appropriate impact prevention measures.
- 2) Carry out the welding work of the piping before installing the flexible joint. If you have to carry out the welding work after installing the flexible joint, take ground the welding electricity, also put a protective cover around the flexible joint so that the welding current does not flow into the piping system.
- Please select the pipie size not to exceed 3m/s of flow velocity. (inside diameter basis)

- In case of corrosive fluid for stainless steel, ZTF series products (fluoro-resin bellows) are recommneded
- In case of steam application, spiral wound gasket shall be recommended.
 Please use our genuine gaskets .
 So, let us know whether our spiral wound gasket shall be attached or not before placing

order.